



**READ ALL WARNINGS AND INSTRUCTIONS PRIOR TO INSTALLING
THE KOBI LED LINEAR HIGH BAY FIXTURE TO ENSURE SAFETY AND PROPER OPERATION**

DO NOT make or alter any open holes in an enclosure of wiring or electrical components during kit installation.

DO NOT install damaged product.

INSTALLERS make certain no bare wires are exposed outside the wire nut connectors.

WARNING - Risk of fire or electric shock. LED Linear High Bay Fixture installation requires knowledge of electrical fixture systems. If not qualified, do not attempt installation. Contact a qualified electrician.

WARNING - To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.

WARNING - This fixture must be installed in accordance with the NEC or your local electrical code. If not familiar with these code and requirements, consult a qualified electrician.

WARNING - Risk of fire. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved

- **Suitable for Damp Locations**
- **Recessed Luminaires for Type IC**

This complete luminaire includes:

- 1 Kobi Electric LED Linear High Bay Fixture
- 1 Installation Instruction Sheet

INSTALLATION INSTRUCTIONS:



DANGER - RISK OF SHOCK
DISCONNECT POWER BEFORE INSTALLATION

Chain & Cable Install:

1. Turn off the circuit breaker and AC switch before working on the light fixture.
2. Install the chain/cable into the provided wire hanger.
3. Secure the other end of the chain/cable to a structure using hardware rated for the load.
4. Install the wire hanger on to the top side of the fixture. Make sure the wiring hangers are fully engaged into the side holes on the fixture.
5. Connect the LED high bay wiring to line wire, black to black, white to white and green to green. Use only UL listed wiring
**NOTE: Purple and grey lead inside the driver compartment are 0-10V (low voltage) dimming leads. Connect to dimming low voltage wiring only.

Pendant Install:

1. Turn off the circuit breaker and AC switch before working on the light fixture.
2. Remove the junction box cover.
3. Mount hanging bracket to fixture with four screws and attach the pendant stem.
4. Connect the LED high bay wiring to line wire, black to black, white to white and green to green. Use only UL listed wiring
**NOTE: Purple and grey lead inside the driver compartment are 0-10V (low voltage) dimming leads. Connect to dimming low voltage wiring only.
5. Put the hanging bracket side plates on and secure with one screw each on top of bracket.

Cable Install



Chain Install



Pendant Install



Wiring Diagram

