

READ ALL WARNINGS AND INSTRUCTIONS PRIOR TO INSTALLING THE KOBI LED VAPOR TIGHT TO ENSURE SAFETY AND PROPER OPERATION

**DO NOT** make or alter any open holes in an enclosure of wiring or electrical components during fixture installation.

**DO NOT** install damaged product. This luminaire has been properly packed so that no parts should have been damaged during transit. Inspect before installation.

**DO NOT** exceed maximum wattage marked on luminaire.

**WARNING** - Risk of fire or electric shock. LED Vapor Tight installation requires knowledge of luminaires electrical systems. If not qualified, do not attempt installation. Contact a qualified electrician.

**WARNING** - To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.

**WARNING** - Verify that supply voltage is correct by comparing it with the luminaire label information.

**WARNING** - Make all electrical and grounded connections in accordance with the NEC and any applicable local code requirements.

## Suitable for Wet Locations

## This includes:

- 1 Kobi Electric LED Vapor Tight
- 1 Safety and Warning Label Sheet
- 1 Installation Instruction Sheet





## SEE REVERSE SIDE - READ ALL WARNINGS AND INSTRUCTIONS PRIOR TO INSTALLING THE KOBI LED VAPOR TIGHT TO ENSURE SAFETY AND PROPER OPERATION

## INSTALLATION INSTRUCTIONS:

**DANGER - RISK OF SHOCK** DISCONNECT POWER BEFORE INSTALLATION

- 1. Disconnect power supply and remove existing fixture (if applicable)
- 2. Carefully remove the PC lens by opening the metal clips, then remove aluminum plate by rotating the plastic knob. (Figure A)
- 3. Screw the two metal brackets to the ceiling, install the housing to the metal brackets.(Figure B)
- 4. Install the end cap, connect wiring to terminal block through the cable entry hole. (Figure C)
- 5. Re-install the aluminum plate and PC lens to the housing. (Figure D)
- 6. Fasten the metal clips. (Figure E)

