



READ ALL WARNINGS AND INSTRUCTIONS PRIOR TO
INSTALLING THE KOBI LED AREA LIGHT TO ENSURE SAFETY AND PROPER OPERATION

DO NOT make or alter any open holes in an enclosure of wiring or electrical components during fixture installation.

DO NOT install damaged product. this luminaire hasbeen properly packed sot that no parts should have been damaged during transit. Inspect before installation.

DO NOT exceed maximum wattage marked on luminaire.

INSTALLERS should not disconnect existing wires from lampholder terminals to make new connections at lampholder terminals. Instead installers should cut existing lampholder leads away from the lampholder and make new electrical connections to lampholder lead wires by employing applicable connectors.

WARNING - Risk of fire or electric shock. LED Area Light installation requires knowledge of luminaires electrical systems. If not qualified, do not attempt installation. Contact a qualified electrician.

WARNING - To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.

WARNING - Risk of fire or electric shock. Install this fixture only in luminaires that have the construction features and dimensions shown in the chart and wiring diagram and where the input rating of the retrofit kit does not exceed the input rating of the luminaire.

WARNING - Verify that supply voltage is correct by comparing it with the luminaire label information.

WARNING - Make all electrical and grounded connections in accordance with the NEC and any applicable local code requirements.

Suitable for Wet Locations

Minimum 90°C Supply Conductors

INSTALLATION INSTRUCTIONS



DANGER - RISK OF SHOCK
DISCONNECT POWER BEFORE INSTALLATION


This includes:

- 1 Kobi Electric LED Area Light
- 1 Installation Instruction Sheet
- 1. Disconnect power supply and remove existing fixture (if applicable)
- 2. The fixture will be supplied with the desired adapter and whip/power cord already fixed to the housing.
- 3. Mounting the fixture:

SIDE ARM -

- 1. Drill bolt pattern into existing pole according to figure A.
- 2. Loosen nuts and remove washers and lock washers from (2) side arm bolts.
- 3. Slip the (2) bolts through the drilled holes, making sure the whip/power cord is pulled through the middle hole and through the pole.
- 4. Replace lock washers, washers, and nuts, then tighten from the inside the pole
- 5. Wire the whip/power cord to the existing power source.


(Figure A)



WALL MOUNT -

- 1. Drill 4 hole bolt pattern into existing surface area according to figure B.
- 2. Wire the whip/power cord to the exsisting power source.
- 3. Secure 4 bolts through wall mount into exsisting surface.

(Figure B)








SEE REVERSE SIDE - READ ALL WARNINGS AND INSTRUCTIONS PRIOR TO INSTALLING THE KOBI LED AREA LIGHT TO ENSURE SAFETY AND PROPER OPERATION

YOKE BRACKET -

(Yoke Bracket should be adjusted to desired angle before installing.)

- 1. Drill bolt pattern into existing pole according to figure C.
- 2. Loosen nuts and remove washers and lock washers from the Yoke Bracket.
- 3. Slip the (2) bolts through the drilled holes, making sure thewhip/power cord is pulled through the middle hole and through the pole.
- 4. Replace lock washers, washers, and nuts, then tighten from the inside the pole.
- 5. Wire the whip/power cord to the existing power source.



3.75" (Figure D) **SLIP FITTER -**(Slip Fitter should be adjusted to the desired angle before mounting) 1. Wire the whip/power cord to the existing power source. Adjusting Mounts Screws 2. Lower the fixture over the tenon making sure not to pinch to wire between the slip fitter and tenon. Fixture 3. Tighten the (2) locking screws located on the side of the slip fitter mount, securing the slip fitter to the pole. 3.125" (Figure D) 6.5" 0 Locking Fits 2 3/8" Pole 3.125" Screws 0

